

S/C Icon2 w/HS Installation instruction manual

PRODUCT DESCRIPTION

SPECIFICATION:


1. AFTER YOU OPEN THE PACKAGE, PLEASE CHECK THE PHYSICAL OBJECT AND THE CORRESPONDING ACCESSORIES.


- 2. THE PICTURE IS ONLY FOR REFERENCE, PLEASE MAKE THE OBJECT AS THE STANDARD.
- ACCESSORIES ARE SUBJECT TO CHANGE WITHOUT AFFECTING USE, NO FURTHER NOTICE.
- 4. THANK YOU FOR CHOOSING OUR PRODUCTS.

THE LIST OF PRODUCTS IS AS FOLLOWS:


PLEASE REFER TO THE FIGURE ON THE RIGHT

09	PLASTIC WRENCH	1	PLASTIC	
08	SPARE PARTS	1	S.S	
07	ACCESSORY BAG	1	S.S	
06	1.5 MM FLEXIBLE HOSE	1	CU	
05	HANDSHOWER	1	S.S	
04	BODY	1	CU	
03	BASEPLATES	1	S.S	
02	SHOWER BRAKET	1	CU	
01	HANDLE	2	CU	
NO	NAME	QTY	MATERIAL	REMARK





DIMENSIONAL DRAWING



INSTALLATION NOTES

IMPORTANT TIPS:

1.1 PRESSURE: UNDER THE PRESSURE 0.1±0.01 MPA, SPOUNT WITH ATTACHMENT FOR BASIN MIXER, SINK & KITCHEN MIXER, ELOW BATE COLL /S

1.2 PRESSURE: UNDER THE PRESSURE 0.3+0.02 MPA, SHOWER MIXER, FLOW RATE≥0.33L/S, BASIN MIXER,BIDET,

SINK & HEADSHOWER, FLOW RATE≥ 0.15L/S.

2.RECOMMENDED WATER INLET TEMPERATURE 4°-80°.

NOTES:

- 1. THE MAIN BODY OF FAUCET IS TESTED BY FACTORY, DON'T PLEASE DO NOT DISASSEMBLE AND ASSEMBLE BY YOURSELF.
- 2. BE SURE TO REMOVE IMPURITIES AND SLUDGE FROM PRE-BURIED PIPES BEFORE INSTALLING FAUCETS.
- 3. AFTER INSTALLING THE FAUCET, PLEASE CHECK THE JOINTS WHETHER ARE TIGHTLY CONNECTED AND THE PIPE IS LEAKING OR NOT.
- 4. PIPE INSTALLATION LEFT FOR HOT WATER, COLD WATER ON THE RIGHT, DO NOT INSTALL THE REVERSE

INSTALLATION STEPS

