







FLOW AIR FLUSH PLATE

Installation Instruction Manual

(Mod. FLO-AIR88 / FLO-AIRSQU)






FLOW AIR FLUSH PLATE

Installation Instruction Manual


(Mod. FLO-AIR88 / FLO-AIRSQU)

INSTALLATION STEPS


01




02




03




04




05



06



07



08

