




FLOW FLUSH PLATE


Installation Instruction Manual

(Mod. FLO-ROU88 / FLO-ROU / FLO-SQU)




ORDER COMPONENTS


01




02



03




04



05



06






FLOW FLUSH PLATE

Installation Instruction Manual


(Mod. FLO-ROU88 / FLO-ROU / FLO-SQU)

INSTALLATION STEPS


01




02




03




04




05




06




07




08




10



11



12



13

